



SERVICE MANUAL BMG-735RS

VERSION 1.4

Index

1. Tools	03
2. Spare parts	04
3. Electric schedules E07081 / 3x 400V	23
4. Fault diagnose frequency drive grinding motor	39



1. Tools

Diamag grinding wings & Accessories



<p>E07240-2 DIAMAG ADAPTER PLATE Ø240 MM</p>	<p>BG707321 #18 - 20 BG707322 #30 - 40 BLUE GRINDING WING</p>	<p>BG707311 #18 - 20 BG707312 #30 - 40 BG707313 #60 - 80 BG707314 #120 - 150 GREEN GRINDING WING</p>	<p>BG707301 #18 - 20 BG707302 #30 - 40 BG707303 #60 - 80 BG707304 #120 - 150 RED GRINDING WING</p>	<p>BG707341-2 #30 - 40 BLACK GRINDING WING</p>
---	---	--	--	---



<p>E10692 DIAMAG ADAPTER PLATE WINGS PCD Ø240 MM</p>	<p>BG200997-1/SET PCD SPLIT WING BG200995-1/SET PCD 1x1 WING</p>	<p>E09580 ROTARY PLATE ONLY Ø240 MM E10240 PLATE Ø240 MM COMPLETE WITH BUSH HAMMER ROLLERS E10240/SW PLATE Ø240 MM COMPLETE WITH STAR WHEELS</p>	<p>E09119-1 BUSH HAMMER ROLLER Ø50 MM BG300109 CUTTER WHEEL Ø50 MM</p>	<p>E09368/FINE VELCRO PLATE Ø240 MM For Polishing pads E09368/COARSE VELCRO PLATE Ø240 MM For Maintenance pads</p>
---	--	---	--	--



<p>BG240001 #40 BG240002 #100 BG240003 #200 BG240004 #400 BG240005 #800 BG240006 #1500 BG240007 #3000</p> <p>POLISHING PADS Ø240 MM</p>	<p>#1 - orange #2 - Black #3 - Blue #4 - Red #5 - White #6 - Yellow #7 - Green</p>
--	--

<p>BG240M004 #400#4 BG240M005 #800#5 BG240M006 #1500 #6 BG240M007 #3000 #7</p> <p>MAINTENANCE PADS Ø240 MM</p>
--


<p>E005014 10 M SUCTION HOSE Ø76 MM</p>
--



<p>E07000 FRONT- TRANSPORT WHEELS (STANDARD WITH BMG-735RS)</p>
--

<p>E07061 REMOTE CONTROL</p>


2. Spare parts Frame complete





Item	Part number	Description	Remarks	Qty.
1	E07032/BL	Handle for steer long		1
2	999-9156	Pipe clamp (set)		2
3	E07882	Operating box complete		1
	E01543	Emergency stop		
	E01318	Start button		
	E01351	Potential meter complete (speed switch)		
	E01323	Left / right switch		
	E05130	Make contact (green)		
	E05131	Brake contact (red)		
4	BE0641	M10 clamp lever		1
5	E06860	Clamping pin steer		1
6	BG11758	Cord for deadman switch		1
7	BG11759	Key for deadman switch		1
8	BG11760	Deadman switch		1
9	BE0674	Handle locking pin		1
10	E06883	Swing arm for dusthose		1
11	478198	Quick release pin		1
12	BE0653	Hook		2
13	E07008	Chain (11links)		1
14	E07204	Electrobox 15kW complete		1
	E07204/UL230	Electrobox 15kW complete 230UL		1
	E07204/UL480	Electrobox 15kW complete 480UL		1
15	E07065	Weight set right		1
	E07066	Weight set left		1
16	E06994-1	Fast locking pin		4
17	E07077	Slide ring		4
18	E07076	Adjust block		2
19	E07049	Traction wheel		2
20	E07057	Bearing		4
21	E07055	Wheel axle		2
22	E07058	Bearing		2
23	E07054	Drive support right		1
	E07053	Drive support left		1
24	E07036	Mounting bush		2
25	E07052/BL	Drive motor		2
26	E07060	Receiver		1
27	E07078	Receiver mount plate		1
28	E07808	Receiver antenna		1
29	E06286	Water coupling		1
30	E06285	Waterhose connection		1
31	E06282	Ball valve mini		1
32	E06279	Water reducing coupling		1
33	E01492	Megi bush		2
34	BG11752	Hinge bolt		2
	E07035	Frame		1
	BG005835	Steer handle		1
	E07083	Frontplate electrobox RS		1
	E07061	Remote transmitter		1


Machine complete





Item	Part number	Description	Remarks	Qty.
35	BG005847	Protection cap		1
36	BG11924	Upper belt		1
37	BG11923-1IE2	Motor 230V/400V		1
38	BE0654	M8x16 set screw	DIN 916	4
39	BG007808_2	Coupling upper part		1
40	BE0656	M14x140 hexagon socket head bolt	DIN 912	3
41	BG007810	Flange motor seat		1
42	BG007811	Motor seat		1
43	BG005844	Coupling plastic star		1
44	BG11829	V-seal		1
45	BE0635	M8x110 hexagon socket head bolt	DIN 912	6
46	BG007808_1	Coupling under part		1
47	BE0188	M6x25 hexagon socket head bolt	DIN 912	1
48	BG007339	Protection cover		1
49	BE0655	M6x12 hexagon shoulder screw		4
50	E06281	Water T-coupling		1
51	E06278	Waterhose		1,5m
52	E06276	Pipe clamp		2
53	E06897	Slide strip		2,5m
54	E06293	Nut for knee coupling		2
55	E06280	Water knee coupling		2
56	E04551	Plastic cap		1
57	BG007349	Brush for floating shroud		1
58	BG007355	Floating shroud		1


Upper drive





Item	Part number	Description	Remarks	Qty.
60	BE0631	M8x40 hexagon socket head bolt	DIN 7984	4
61	BG005856	Contra pulley		1
62	BE0648	Key 8x7x18	DIN 6885A	1
63	BG005805-1	Pulley		1
64	E01560	Taperlock		1
65	BE0443	M10x25 hexagon socket head bolt		
66	BG005860	Upper tensioner		1
67	BG005813	Holder		2
68	BG005809	Motorplate complete		1
69	BG005857	Centre pulley		1
70	BG11904	Middle belt		1
71	BG005834	Lower plate upper drive		1
72	BG005807	Ring		1
73	BG007804	Flange		1
74	BE0350	M6x10 hexagon head screw		8


Lower drive






Item	Part number	Description	Remarks	Qty.
75	BG005814	Ring		1
76	BG11849	V-seal		1
77	BE0617	M6x50 countersunk screw	DIN 7991	2
78	BE0051	M6x25 hexagon head bolt	DIN 933	18
79	BG005827	Cover		4
80	BE0030	M8x25 hexagon head bolt	DIN 933	4
81	BG007322	Housing complete		1
82	BG005832-1	Holder		1
83	BE0090	M8x40 hexagon head bolt	DIN 933	1
84	BG005858	Drive pulley		1
85	BG005859	Pulley		3
86	BG11940	Lower belt		1
87	BG005861	Lower tensioner		1
88	BG007324	Lower plate 735PRO		1
89	BE0035	M6x16 hexagon socket head bolt	DIN 912	18
90	BE0188	M6x25 hexagon socket head bolt	DIN 912	24
91	BG007850	Inspection cover		2
92	BE0082	M8x12 hexagon socket head bolt	DIN 912	6
93	BG0005826	Ring		3
94	BG11797	V-seal		3

Contra pulley BG005856



Item	Part number	Description	Remarks	Qty.
100	BG005803	Belt pulley		1
101	BE0109	Key 8x7x20	DIN 6885A	1
102	BE0076	Retaining ring for shaft Ø25	DIN 471	1
103	BG005802	Bearing house		1
104	BE0077	Retaining ring for bore Ø52	DIN 472	4
105	222-2331-E	Bearing		2
106	BG005801	Axle		1

Centre pulley BG005857



Item	Part number	Description	Remarks	Qty.
108	BG005812	Sprocket		1
109	E03703	V-seal		1
110	BG005806	Pulley		1
111	E01490	Bearing		1
112	E03993	Retaining ring for bore Ø90	DIN 472	1
113	BE0126	Retaining ring for shaft Ø50	DIN 471	1




Drive pulley BG005858




Item	Part number	Description	Remarks	Qty.
115	B20404	Bearing		2
116	BG005815	Bearing house		1
117	BE0256	Key 8x7x30	DIN 6885A	1
118	BG005818	Axle		1
119	BE0269	Key 10x8x32	DIN 6885A	1
120	E00718	Taperlock		1
121	BG005820	Pulley		1
122	E00951	Retaining ring for bore $\varnothing 62$	DIN 472	4
123	BG005821	Bearing house		1
124	B21631	Retaining ring for shaft $\varnothing 30$	DIN 471	2

Pulley (3x) BG005859




Item	Part number	Description	Remarks	Qty.
127	B21631	Retaining ring for shaft Ø30	DIN 471	3
128	RB100A3-350	Taperlock		1
129	RB165-2	Pulley		1
130	BG11817	Bearing		2
131	BG005816	Axle		1
132	E00951	Retaining ring for bore Ø62	DIN 472	4
133	BG005817	Bearing house		1
134	BE0256	Key 8x7x30	DIN 6885A	1

Upper tensioner BG005860




Item	Part number	Description	Remarks	Qty.
136	BE0074	Retaining ring for shaft Ø20	DIN 471	1
137	222-2245	Bearing		2
138	BG005830	Axle for tensioner		1
139	BG005831	Tension plate		1
140	BE0130	M10x25 countersunk screw	DIN 7991	1

Lower tensioner BG005861




Item	Part number	Description	Remarks	Qty.
143	BE0070	Retaining ring for shaft Ø15	DIN 471	2
144	BG11792	Bearing		2
145	BE0618	Retaining ring for bore Ø35	DIN 472	4
146	BG005836	Pulley		1
147	BG005837	Axle tensioner		1
148	BE0458	M8x25 countersunk screw	DIN 7991	2
149	BG005833	Tensioner		1

Buffer plate for surface preparation (3x)



Item	Part number	Description	Remarks	Qty.
153-160	BG240190-1	240mm diamond holder complete		1
156-160	BG2401901-1	240mm diamond holder		1
150	BG11880-HD	Fork		1
151	BE0204 + BE0584	M8x25 hexagon socket head bolt small + M8 spring washer small	DIN 7984 DIN 7980	3
152	BG11879	Buffer disc		1
153	BG11878	Buffer hard		4
154	BE0082	M8x12 hexagon socket head bolt	DIN 912	8
155	BG11877	Magnet plate holder 240mm		1
156	BG2401901-1	Only complete with parts 157 - 160		1
157	BE0456	M8x16 countersunk screw	DIN 7991	3
158	BG11811	Centering star		3
159	BG11810	M6x10 countersunk screw	DIN 7991	6
160	E06446	Magnet		3
161	BE0608	Retaining ring for bore Ø58	DIN 472	1
162	BE0030	M8x25 hexagon head bolt	DIN 933	1
163	BE0314	M8x30x1,5 washer		2
164-169	BG300117	240mm cutter housing complete		1
164	BG300501-1	185mm cutter housing		1
165+166	BG300133	Locking pin & screw		6
167	BG300130	Axle		3
168	BG300109	Cutter		12
169	MPL48	Washer		15
170	E07240	DIAMAG 240mm adapter plate		1
	BG200993-1	Plate for wings 240mm		1
	BG200988-1	Dry polish dot holder 240mm		1
171		DIAMAG grinding wings		3
172	E06447	DIAMAG adapter plate for dots		3
173		Dry polish dots		3

Buffer plate for polishing (3x)






Item	Part number	Description	Remarks	Qty.
175	BE0589	7/16 x 2"½ hexagon UNC bolt		4
176	BG2402001	Flexplate adapter for axle		1
177	BE0012	M8x25 hexagon socket head bolt	DIN 912	3
178	BG400310	Morflex coupling		1
179-182	BG2402002-1	Flexplate diamond holder		1
179	BG24020021-1	Flexplate diamond holder only		1
180	E06446	Magnet		3
181	BG11811	Centering star		3
182	BG11810	M6x10 countersunk screw		6
183	BE0456	M8x16 countersunk screw	DIN 7991	3
184	E07240	DIAMAG 240mm adapter plate		1
	BG200993-1	Plate for wings 240mm		1
	BG200988-1	Dry polish dot holder 240mm		1
185		DIAMAG grinding wings		3
186	E06447	DIAMAG adapter plate for dots		3
187		Dry polish dots		3




3. Electric schedules


E07081 / 3x 400V / 15kW / SC + RC









	auxiliary contact	hulpcontact		signallamp		Safety fuse	smeltveiligheid
	Power contact	vermogenscontact		hoorn		Fused switch, three-pole	schakelbare scheid
	NO contact, opens with time delay	maakcontact, vertraagd open		apm-meter		Fused disconnect, three-pole	scheider "klapbak"
	NO contact, closes with time delay	maakcontact, vertraagd sluitend		running hour counter		Main switch	hoofdschakelaar
	NC contact, opens with time delay	verbodcontact, vertraagd open		transformator		Circuit breaker, single-pole	inzaalautomaat 1-poolig
	NC contact, closes with time delay	verbodcontact, vertraagd sluitend		Contactor/relay coil		Circuit breaker, two-pole	inzaalautomaat 2-poolig
	Pushbutton rebound	drukknop terugveerd		Contactor/relay coil with pick-up delay		Circuit breaker, three-pole	inzaalautomaat 3-poolig
	Pushbutton locking	drukknop blijvend		Contactor/relay coil with drop-out delay		Power circuit breaker motor overload switch with switch mechanism	motorveiligingsschakelaar
	Rotary switch rebound	tip draaischakelaar		Tube light		Valve	elektrisch bediende klep
	Rotary switch locking	draaischakelaar		Resistor / Heating		Resistor with movable contact	regelbare weerstand
	Emergency stop rotary unlock	stopknop met draaibare vrijgave		Socket		Terminal	rijgklem
	Thermostatic switch	thermostaat		Current transformer		Terminal with fuse	rijgklem met zekering
	Pressure switch	drukschakelaar				Rectifier	geijkrichter
	Limit switch	eindschakelaar					
	Proximity switch	naderingsschakelaar					















Par. Settings
 CE2 = 7
 CE1 = 6
 CI2 = 1.5
 CI3 = 1.5







Terminal diagram

function text	Strip X3						Cable name	cable type	Page / column
	Target designation	Connection point	terminal	jumper	Target designation	Connection point			
	1401	59	1		1102	13		14.2	
		52	2		1102	15		14.2	
		52	3		1102	16		14.2	
		51	4					14.3	
		54	5					14.3	
	1401	62	6		11K1.1	42		14.4	
		53	7					14.4	
		50	8					14.4	
		49	9		1102	18		14.5	
		45	10		1102	11		14.5	
	1401	61	11					14.5	
		41	12		1102	12		14.6	
		37	13		1102	17		14.6	
		33	14					14.6	
		29	15					14.7	
		16	16		1401	1		14.6	
		17	17		1401	1		14.7	
		18	18		1401	2		14.7	
		19	19		1401	3		14.7	
		20	20		1401	4		14.7	
		21	21		1002	8		14.7	
		35	22		1003	8		14.8	
		31	23		1001	A2		14.8	
	1401	55	24					14.1	
		25	25		1401	6		14.7	
		26	26		1401	7		14.8	
	1401	9	27		11K1.1	41		14.1	
		13	28		14K1	A1		14.1	
	1401	17	29					14.1	
		21	30		14K2	A1		14.1	
	1401	1	31		11K1.1	41		14.0	
		5	32		1003:14K1	7A2		14.0	
			33		1401	8		14.8	
	1401		PE					14.6	



Parts list

Blastrac rev1 F01_001

device tag	Quantity	designation	Type number	Brand	Blastrac number
CAB	1	Endeavour 400x600x300 with mounting plate 350x530	84002 - ENNM09120029	SAR	
CRB	1	Endeavour RAL7035/7016 for 4 buttons	XAL D04	TEL	
1001	1	63A CEE form Plug 6H 1967	ABL 555535	ABL	
1001	1	Albow 71 Variable Speed Drive	ATV71HD5N4	SE	3-phase supply voltage: 380...480V 50/60Hz
1002	1	Frequency inverter	ES00371L1D1A	LENZE	
1002	1	Motor circuit breaker	GV7 H606	TEL	
1003	1	Frequency inverter	ES00371L1D1A	LENZE	
1003	1	Motor circuit breaker	GV7 H606	TEL	
1004	1	Non-Frigh-Motor 1.0 1.6 A	AB108534030	SCHN	
1004	1	Power supply 400/24V 3A	Z85 HFC0	TEL	
1005	1	Motor circuit breaker	Z85 HFC0	TEL	
1152	1	element IIC with mountingbase	Z85 H202	TEL	
1152	1	Legend holder	Z82 15	SCHN	
1181.1	1	Interface relay 4xCO 24Vdc	MY4 IPU-D2 24VDC	OHR	
1181.1	1	Clip and Release lever	PYC35	OHR	
1181.1	1	RELAYS SOCKET	PVF-4-LE55	OHR	
1181.1	1	Emergency stop relay	XPS-A5121	SCHN	
11N52	1	Safety switch + Pin	XCS-AN79 + XCS-Z11	TEL	
11N51	1	Emergency stop	Z85 AS844	TEL	
11N51	2	element IIC XAL	ZEN L1121	TEL	
11U2	1	PLC logo	SIEM 6ED1052-1J000-0B45	SIE	
11U2	1	Siemens logo Memory Module Brown	SIEM 6ED1056-5CA00-0B40	SIE	
11U2	1	PLC logo expansion module	SIEM 6ED1055-1J000-0B40	SIE	
1151	1	Pushbutton GREEN "START"	Z85 MA323	TEL	
1151	1	element IIO XAL	ZEN L1111	TEL	
1251	1	Switch handle	Z85 A02	TEL	
1251	1	element IIC XAL	ZEN L1121	TEL	
1251	1	element IIO XAL	ZEN L1111	TEL	
12R1	1	Trim-pot 10K	Potmeter LUK Z94	GEN	
12R1	1	Acuwater	Z85 A0912	TEL	
12R1	1	Pin 24Vdc	FAN 8314	EBM	
12R1	1	Pin Blower	ESM	ESM	
13H1	1	Fan Ringer Guard	94252-0116	AKE	
14U1	1	Antenna Cable RP-SMAm CONT 1M	93262-000	AKE	
14U1	1	Bulk for MCS8	93252-000	AKE	
14U1	1	Bulk for MCS8	993862-000	AKE	
14U1	1	Charger for Battery MCS8 of the MCS8 tranom	94266-000	AKE	
14U1	1	Radio control Transmitter MCS8	T-Rx 1500	AKE	
14U1	1	Radio control Receiver T-Rx 1500	94216-000	AKE	
14U1	1	Antenna Cable RP-SMAm CONT 1M	GR-2-SND1-24	OHR	
14K1	1	Interface relay 2xCO 24Vdc	P2CH-S	OHR	
14K1	1	Clip and Release lever	P2RF-08-E	OHR	
14K1	1	Relay socket	P2CH-S	OHR	
14K2	1	Interface relay 2xCO 24Vdc	GR-2-SND1-24	OHR	
14K2	1	Clip and Release lever	P2RF-08-E	OHR	
14K2	1	Relay socket	P2CH-S	OHR	
X1	1	End plate Z0U 2.5	WEI ZAP1TW 1	WEI	
X1	6	2 Wire terminal 2.5mm²	WEI ZDU 2.5	WEI	
X1	1	End bracket	WEI ZEW 35	WEI	
X1	4	2 Wire PE terminal 2.5mm²	WEI ZSE 2.5/	WEI	
X2	2	End bracket	WEI ZEW 35	WEI	
X2	1	Double level PE terminal 2.5mm²	WEI ZDK 2.5PE	WEI	
X2	6	Double level terminal 2.5mm²	WEI ZDK 2.5	WEI	
X2	1	End plate Z0U 2.5	WEI ZAP1TW ZDK2.5-08	WEI	
X3	1	End plate Z0U 2.5	WEI ZAP1TW ZDK2.5-08	WEI	
X3	17	Double level terminal 2.5mm²	WEI ZDK 2.5	WEI	

4. Fault diagnose frequency drive

For a complete overview of faults and how to resolve them, check the operating manual of the frequency drive or the CD, which are delivered with the machine.

If you put the CD in the computer, it will automatically go to the manuals.

Does the inverter shows an "INF" fault, reset the machine.

If the machine does not work after that, call you distributor.

To reset the machine, put out the power supply and wait 5 minutes.

Then start up the machine again. Call a technician if the machine still not works.

Fault	Name	Probable cause	Remedy
R I 2 F	[AI2 input]	<ul style="list-style-type: none"> Non-conforming signal on analog input AI2 	<ul style="list-style-type: none"> Check the wiring of analog input AI2 and the value of the signal
R n F	[Load slipping]	<ul style="list-style-type: none"> The encoder speed feedback does not match the reference 	<ul style="list-style-type: none"> Check the motor, gain and stability parameters Add a braking resistor Check the size of the motor/drive/load Check the encoder's mechanical coupling and its wiring
b D F	[DBR overload]	<ul style="list-style-type: none"> The braking resistor is under excessive stress 	<ul style="list-style-type: none"> Check the size of the resistor and wait for it to cool down Check the [DB Resistor Power] (brP) and [DB Resistor value] (brU) parameters, page 211
b r F	[Brake feedback]	<ul style="list-style-type: none"> The brake feedback contact does not match the brake logic control 	<ul style="list-style-type: none"> Check the feedback circuit and the brake logic control circuit Check the mechanical state of the brake
b U F	[DB unit sh. Circuit]	<ul style="list-style-type: none"> Short-circuit output from braking unit 	<ul style="list-style-type: none"> Check the wiring of the braking unit and the resistor Check the braking resistor
C r F 1	[Precharge]	<ul style="list-style-type: none"> Load relay control fault or charging resistor damaged 	<ul style="list-style-type: none"> Switch the drive off and then back on again Check the internal connections
C r F 2	[Thyr. soft charge]	<ul style="list-style-type: none"> DC bus charging fault (thyristors) 	<ul style="list-style-type: none"> Inspect/repair the drive
E C F	[Encoder coupling]	<ul style="list-style-type: none"> Break in encoder's mechanical coupling 	<ul style="list-style-type: none"> Check the encoder's mechanical coupling
E E F 1	[Control Eeprom]	<ul style="list-style-type: none"> Internal memory fault, control card 	<ul style="list-style-type: none"> Check the environment (electromagnetic compatibility) Turn off, reset, return to factory settings
E E F 2	[Power Eeprom]	<ul style="list-style-type: none"> Internal memory fault, power card 	<ul style="list-style-type: none"> Inspect/repair the drive
E n F	[Encoder]	<ul style="list-style-type: none"> Encoder feedback fault 	<ul style="list-style-type: none"> Check [Number of pulses] (PGI) and [Encoder type] (EnS), page 72 Check that the encoder's mechanical and electrical operation, its power supply and connections are all correct If necessary, reverse the direction of rotation of the motor ([Output Ph rotation] (PHr) parameter, page 88) or the encoder signals
F C F 1	[Out. contact. stuck]	<ul style="list-style-type: none"> The output contactor remains closed although the opening conditions have been met 	<ul style="list-style-type: none"> Check the contactor and its wiring Check the feedback circuit



Fault	Name	Probable cause	Remedy
H d F	[IGBT desaturation]	<ul style="list-style-type: none"> Short-circuit or grounding at the drive output 	<ul style="list-style-type: none"> Check the cables connecting the drive to the motor, and the insulation of the motor Perform the diagnostic tests via the [1.10 DIAGNOSTICS] menu
IL F	[Internal com. link]	<ul style="list-style-type: none"> Communication fault between option card and drive 	<ul style="list-style-type: none"> Check the environment (electromagnetic compatibility) Check the connections Check that no more than 2 option cards (max. permitted) have been installed on the drive Replace the option card Inspect/repair the drive
Inf 1	[Rating error]	<ul style="list-style-type: none"> The power card is different from the card stored 	<ul style="list-style-type: none"> Check the reference of the power card
Inf 2	[Incompatible PB]	<ul style="list-style-type: none"> The power card is incompatible with the control card 	<ul style="list-style-type: none"> Check the reference of the power card and its compatibility
Inf 3	[Internal serial link]	<ul style="list-style-type: none"> Communication fault between the internal cards 	<ul style="list-style-type: none"> Check the internal connections Inspect/repair the drive
Inf 4	[Internal MFG area]	<ul style="list-style-type: none"> Internal data inconsistent 	<ul style="list-style-type: none"> Recalibrate the drive (performed by Schneider Electric Product Support)
Inf 5	[Internal-option]	<ul style="list-style-type: none"> The option installed in the drive is not recognized 	<ul style="list-style-type: none"> Check the reference and compatibility of the option
Inf 7	[Internal-hard init.]	<ul style="list-style-type: none"> Initialization of the drive is incomplete 	<ul style="list-style-type: none"> Turn off and reset
Inf 8	[Internal-ctrl supply]	<ul style="list-style-type: none"> The control power supply is incorrect 	<ul style="list-style-type: none"> Check the control power supply
Inf 9	[Internal- I measure]	<ul style="list-style-type: none"> The current measurements are incorrect 	<ul style="list-style-type: none"> Replace the current sensors or the power card Inspect/repair the drive
Inf R	[Internal-mains circuit]	<ul style="list-style-type: none"> The input stage is not operating correctly 	<ul style="list-style-type: none"> Perform the diagnostic tests via the [1.10 DIAGNOSTICS] menu Inspect/repair the drive
Inf b	[Internal- th. sensor]	<ul style="list-style-type: none"> The drive temperature sensor is not operating correctly 	<ul style="list-style-type: none"> Replace the temperature sensor Inspect/repair the drive
Inf C	[Internal-time meas.]	<ul style="list-style-type: none"> Fault on the electronic time measurement component 	<ul style="list-style-type: none"> Inspect/repair the drive
Inf E	[Internal- CPU]	<ul style="list-style-type: none"> Internal microprocessor fault 	<ul style="list-style-type: none"> Turn off and reset. Inspect/repair the drive
OC F	[Overcurrent]	<ul style="list-style-type: none"> Parameters in the [SETTINGS] (SEt-) and [1.4 MOTOR CONTROL] (drC-) menus are not correct Inertia or load too high Mechanical locking 	<ul style="list-style-type: none"> Check the parameters Check the size of the motor/drive/load Check the state of the mechanism
P r F	[Power removal]	<ul style="list-style-type: none"> Fault with the drive's "Power removal" safety function 	<ul style="list-style-type: none"> Inspect/repair the drive
SC F 1	[Motor short circuit]	<ul style="list-style-type: none"> Short-circuit or grounding at the drive output 	<ul style="list-style-type: none"> Check the cables connecting the drive to the motor, and the insulation of the motor Perform the diagnostic tests via the [1.10 DIAGNOSTICS] menu
SC F 2	[Impedant sh. circuit]	<ul style="list-style-type: none"> Significant earth leakage current at the drive output if several motors are connected in parallel 	<ul style="list-style-type: none"> Reduce the switching frequency Connect chokes in series with the motor
SC F 3	[Ground short circuit]		
SD F	[Overspeed]	<ul style="list-style-type: none"> Instability or driving load too high 	<ul style="list-style-type: none"> Check the motor, gain and stability parameters Add a braking resistor Check the size of the motor/drive/load
SP F	[Speed fedback loss]	<ul style="list-style-type: none"> Encoder feedback signal missing 	<ul style="list-style-type: none"> Check the wiring between the encoder and the drive Check the encoder
t n F	[Auto-tuning]	<ul style="list-style-type: none"> Special motor or motor whose power is not suitable for the drive Motor not connected to the drive 	<ul style="list-style-type: none"> Check that the motor/drive are compatible Check that the motor is present during auto-tuning If an output contactor is being used, close it during auto-tuning



Fault	Name	Probable cause	Remedy
A P F	[Application fault]	<ul style="list-style-type: none"> Controller Inside card fault 	<ul style="list-style-type: none"> Please refer to the card documentation
b L F	[Brake control]	<ul style="list-style-type: none"> Brake release current not reached Brake engage frequency threshold [Brake engage freq] (bEn) only regulated when brake logic control is assigned 	<ul style="list-style-type: none"> Check the drive/motor connection Check the motor windings Check the [Brake release I FW] (lbr) and [Brake release I Rev] (lrd) settings, page 148. Apply the recommended settings for [Brake engage freq] (bEn)
C n F	[Com. network]	<ul style="list-style-type: none"> Communication fault on communication card 	<ul style="list-style-type: none"> Check the environment (electromagnetic compatibility) Check the wiring Check the time-out Replace the option card Inspect/repair the drive
C D F	[CAN com.]	<ul style="list-style-type: none"> Interruption in communication on the CANopen bus 	<ul style="list-style-type: none"> Check the communication bus Check the time-out Refer to the CANopen user's manual
E P F 1	[External flt-LI/Bit]	<ul style="list-style-type: none"> Fault triggered by an external device, depending on user 	<ul style="list-style-type: none"> Check the device, which caused the fault, and reset
E P F 2	[External fault com.]	<ul style="list-style-type: none"> Fault triggered by a communication network 	<ul style="list-style-type: none"> Check for the cause of the fault and reset
F C F 2	[Out. contact. open.]	<ul style="list-style-type: none"> The output contactor remains open although the closing conditions have been met 	<ul style="list-style-type: none"> Check the contactor and its wiring Check the feedback circuit
L C F	[input contactor]	<ul style="list-style-type: none"> The drive is not turned on even though [Mains V. time out] (LCt) has elapsed 	<ul style="list-style-type: none"> Check the contactor and its wiring Check the time-out Check the line/contactor/drive connection
L F F 2 L F F 3 L F F 4	[AI2 4-20mA loss] [AI3 4-20mA loss] [AI4 4-20mA loss]	<ul style="list-style-type: none"> Loss of the 4-20 mA reference on analog input AI2, AI3 or AI4 	<ul style="list-style-type: none"> Check the connection on the analog inputs
D b F	[Overbraking]	<ul style="list-style-type: none"> Braking too sudden or driving load 	<ul style="list-style-type: none"> Increase the deceleration time Install a braking resistor if necessary Activate the [Dec ramp adapt.] (brA) function, page 127, if it is compatible with the application
D H F	[Drive overheat]	<ul style="list-style-type: none"> Drive temperature too high 	<ul style="list-style-type: none"> Check the motor load, the drive ventilation and the ambient temperature. Wait for the drive to cool down before restarting
D L F	[Motor overload]	<ul style="list-style-type: none"> Triggered by excessive motor current 	<ul style="list-style-type: none"> Check the setting of the motor thermal protection, check the motor load. Wait for the drive to cool down before restarting
D P F 1	[1 output phase loss]	<ul style="list-style-type: none"> Loss of one phase at drive output 	<ul style="list-style-type: none"> Check the connections from the drive to the motor



Fault	Name	Probable cause	Remedy
D P F 2	[3 output phase loss]	<ul style="list-style-type: none"> • Motor not connected or motor power too low • Output contactor open • Instantaneous instability in the motor current 	<ul style="list-style-type: none"> • Check the connections from the drive to the motor • If an output contactor is being used, parameterize [Output Phase Loss] (OPL) = [Output cut] (OAC), page 201 • Test on a low power motor or without a motor: In factory settings mode, motor phase loss detection is active [Output Phase Loss] (OPL) = [Yes] (YES). To check the drive in a test or maintenance environment, without having to use a motor with the same rating as the drive (in particular for high power drives), deactivate motor phase loss detection [Output Phase Loss] (OPL) = [No] (nO) • Check and optimize the following parameters: [IR compensation] (UFR), page 20, [Rated motor volt.] (UnS) and [Rated mot. current] (nCr), page 85, and perform [Auto tuning] (tUn), page 88
D S F	[Mains overvoltage]	<ul style="list-style-type: none"> • Mains voltage too high • Disturbed mains supply 	<ul style="list-style-type: none"> • Check the mains voltage
D t F 1	[PTC1 overheat]	<ul style="list-style-type: none"> • Overheating of the PTC1 probes detected 	<ul style="list-style-type: none"> • Check the motor load and motor size • Check the motor ventilation • Wait for the motor to cool before restarting • Check the type and state of the PTC probes
D t F 2	[PTC2 overheat]	<ul style="list-style-type: none"> • Overheating of the PTC2 probes detected 	
D t F L	[LI6=PTC overheat]	<ul style="list-style-type: none"> • Overheating of PTC probes detected on input LI6 	
P t F 1	[PTC1 probe]	<ul style="list-style-type: none"> • PTC1 probes open or short-circuited 	
P t F 2	[PTC2 probe]	<ul style="list-style-type: none"> • PTC2 probes open or short-circuited 	<ul style="list-style-type: none"> • Check the PTC probes and the wiring between them and the motor/drive
P t F L	[LI6=PTC probe]	<ul style="list-style-type: none"> • PTC probes on input LI6 open or short-circuited 	
S C F 4	[IGBT short circuit]	<ul style="list-style-type: none"> • Power component fault 	
S C F 5	[Motor short circuit]	<ul style="list-style-type: none"> • Short-circuit at drive output 	<ul style="list-style-type: none"> • Check the cables connecting the drive to the motor, and the motor's insulation • Perform diagnostic tests via the [1.10 DIAGNOSTICS] menu • Inspect/repair the drive
S L F 1	[Modbus com.]	<ul style="list-style-type: none"> • Interruption in communication on the Modbus bus 	<ul style="list-style-type: none"> • Check the communication bus • Check the time-out • Refer to the Modbus user's manual
S L F 2	[PowerSuite com.]	<ul style="list-style-type: none"> • Fault communicating with PowerSuite 	<ul style="list-style-type: none"> • Check the PowerSuite connecting cable • Check the time-out
S L F 3	[HMI com.]	<ul style="list-style-type: none"> • Fault communicating with the graphic display terminal 	<ul style="list-style-type: none"> • Check the terminal connection • Check the time-out
S r F	[Torque time-out]	<ul style="list-style-type: none"> • The time-out of the torque control function is attained 	<ul style="list-style-type: none"> • Check the function's settings • Check the state of the mechanism
S S F	[Torque/current lim]	<ul style="list-style-type: none"> • Switch to torque limitation 	<ul style="list-style-type: none"> • Check if there are any mechanical problems • Check the parameters of [TORQUE LIMITATION] (tLA-) page 171 and the parameters of fault [TORQUE OR I LIM. DETECT.] (tld-), page 210
t J F	[IGBT overheat]	<ul style="list-style-type: none"> • Drive overheated 	<ul style="list-style-type: none"> • Check the size of the load/motor/drive • Reduce the switching frequency • Wait for the motor to cool before restarting

Fault	Name	Probable cause	Remedy
C F F	[Incorrect config.]	<ul style="list-style-type: none"> Option card changed or removed Control card replaced by a control card configured on a drive with a different rating The current configuration is inconsistent 	<ul style="list-style-type: none"> Check that there are no card errors In the event of the option card being changed/removed deliberately, see the remarks below Check that there are no card errors In the event of the control card being changed deliberately, see the remarks below Return to factory settings or retrieve the backup configuration, if it is valid (see page 223)
C F I	[Invalid config.]	<ul style="list-style-type: none"> Invalid configuration <p>The configuration loaded in the drive via the bus or communication network is inconsistent</p>	<ul style="list-style-type: none"> Check the configuration loaded previously Load a compatible configuration
H C F	[Cards pairing]	<ul style="list-style-type: none"> The [CARDS PAIRING] (PPI-) function, page 212, has been configured and a drive card has been changed 	<ul style="list-style-type: none"> In the event of a card error, reinsert the original card Confirm the configuration by entering the [Pairing password] (PPI) if the card was changed deliberately
P H F	[Input phase loss]	<ul style="list-style-type: none"> Drive incorrectly supplied or a fuse blown Failure of one phase 3-phase ATV71 used on a single-phase line supply Unbalanced load <p>This protection only operates with the drive on load</p>	<ul style="list-style-type: none"> Check the power connection and the fuses Use a 3-phase mains supply Disable the fault by [Input phase loss] (IPL) = [No] (nO) (page 202)
U S F	[Undervoltage]	<ul style="list-style-type: none"> Line supply too low Transient voltage dip Damaged pre-charge resistor 	<ul style="list-style-type: none"> Check the voltage and the parameters of [UNDERVOLTAGE MGT] (USb-), page 205 Replace the pre-charge resistor Inspect/repair the drive



Headquarter

Blastrac The Netherlands

Utrechthaven 12
 NL – 3433 PN Nieuwegein
 Tel – 0031 30 601 88 66
 Fax – 0031 30 601 83 33
 Info@blastrac.nl

Blastrac Poland

Golina, Dworcowa 47a
 PL – 63-200 Jarocin
 Tel – 0048 627 40 41 50
 Fax – 0048 627 40 41 51
 Info@blastrac.pl

Blastrac Italy

S.S. 10 Padana Inferiore, 41
 IT – 29012 Caorso (PC)
 Tel – 0039 0523 81 42 41
 Fax – 0039 0523 81 42 45
 Info@blastrac.it

Blastrac United Kingdom

Unit 2, Outgang Lane, Dinnington
 Sheffield, South Yorkshire
 GB – S25 3QY, England
 Tel – 0044 1909 56 91 18
 Fax – 0044 1909 56 75 70
 Info@blastrac.co.uk

Blastrac Germany

Richard Byrd Straße 15
 D – 50829 Köln (Ossendorf)
 Tel – 0049 221 70 90 32 0
 Fax – 0049 221 70 90 32 22
 Info@blastrac.de

Blastrac Spain

Calle Copernico, 16
 Nave 2
 E – 28820 Coslada
 Tel – 0034 91 660 10 65
 Fax – 0034 91 672 72 11
 Info@blastrac.com.es

Blastrac France (ZI)

29, Avenue des Temps Modernes
 F – 86360 Chasseneuil du Poitou
 Tel – 0033 549 00 49 20
 Fax – 0033 549 00 49 21
 Info@blastrac.fr

Blastrac Ukraine

Nezalezhnosti 14, of. 21
 UA – 07400 Brovary
 Tel – 0038 44 222 51 28
 Fax – 0038 44 277 98 29
 Info@blastrac.com.ua