

DCR300

Reservdelar

Spare parts

Ersatzteile

Pieces de rechange


Piezas de repuesto

Ricambi

Peças sobresselente


Part No.	Page	Description	Part No.	Page	Description
510 19 51-07	A	Hose assy			
510 19 51-08	A	Hose assy			
510 25 87-01	A	Adapter			
510 26 46-01	A	Adapter			
510 26 80-01	A	Quick coupling			
510 26 81-01	A	Quick coupling			
510 36 15-01	A	Screw			
579 00 93-01	A	Cutter			
579 00 94-01	A	Bushing			
579 00 95-01	A	Bushing			
579 00 96-01	A	Cylinder			
579 00 97-01	A	Shaft			
579 00 98-01	AB	Lubrication nipple			
579 00 99-01	A	Sealing			
579 01 00-01	A	Cover plate			
579 01 01-01	A	Cylinder cover			
579 01 02-01	A	Shaft			
579 01 03-01	A	Nut			
579 01 04-01	A	Shaft			
579 01 05-01	A	Nut			
579 01 06-01	A	Adapter plate			
579 01 07-01	A	Filter			
579 01 08-01	A	Bearing			
579 01 10-01	B	Manifold			
579 01 11-01	A	Booster			
579 01 85-01	A	Crusher tip			
579 01 88-01	A	Jaw			
579 01 89-01	B	Plug			
579 01 91-01	B	Sealing			
579 01 92-01	B	Plug			
579 01 93-01	B	Check valve			
579 01 96-01	B	Check valve			
579 01 98-01	B	O-ring			
579 01 99-01	B	O-ring			
579 02 02-01	B	Sealing			
579 02 03-01	B	Plug			
579 02 08-01	B	Hose			
579 02 09-01	B	Hose			
579 02 10-01	B	Hose			
579 02 11-01	B	Hose			
579 02 12-01	B	Adapter			
579 02 13-01	B	Valve			
579 02 14-01	B	Pipe			
579 02 15-01	B	Adapter			
579 02 16-01	B	Support ring			
579 02 17-01	B	Booster			
579 02 18-01	B	Adapter plate			
579 02 19-01	B	Adapter			
579 02 20-01	B	Valve			
579 02 22-01	B	Valve			
579 02 24-01	B	Manifold			
579 02 25-01	B	Slide ring			
579 02 27-01	B	Swivel			
579 02 28-01	B	Swivel bracket			
579 02 58-01	A	Screw			
579 02 64-01	A	Screw			
579 02 65-01	A	Crusher tip			
579 02 67-01	B	Pipe			
579 03 77-01	B	Plug			
579 04 23-01	B	Screw			
579 04 24-01	B	Screw			
579 04 89-01	B	Sealing			
579 04 90-01	B	Adapter			
579 06 47-01	A	Fastener kit			
725 54 53-01	A	Screw			
725 54 91-01	AB	Screw			
725 54 93-01	A	Screw			
734 11 72-01	A	Washer			
734 11 78-01	A	Washer			

A ACCESORIES CONCRETE CRUSCHER DCR 300



Position	Article	Description	Qty	Notes	Kit
1	510 26 80-01	Quick coupling	1		
2	510 26 81-01	Quick coupling	1		
3	510 26 46-01	Adapter	2		
4	510 19 51-07	Hose assy	2		
5	510 25 87-01	Adapter	6		
6	579 01 07-01	Filter	2		
7	510 19 51-08	Hose assy	2		
8	579 00 95-01	Bushing	2		
9	579 00 96-01	Cylinder	2		
10	579 00 97-01	Shaft	2		
11	579 00 98-01	Lubrication nipple	7		
12	725 54 91-01	Screw	2		
13	579 01 01-01	Cylinder cover	2		
14	579 00 93-01	Cutter	2		
15	579 01 02-01	Shaft	2		
16	579 01 04-01	Shaft	2		
17	579 00 94-01	Bushing	2		
18	579 01 00-01	Cover plate	1		
19	579 01 08-01	Bearing	1		
20	734 11 78-01	Washer	16		
21	579 02 64-01	Screw	16		
22	579 01 06-01	Adapter plate	1		
23	725 54 93-01	Screw	16		
24	734 11 72-01	Washer	16		
25	579 06 47-01	Fastener kit	2		26
26	579 01 85-01	Crusher tip	2		
27	579 01 11-01	Booster	1		
28	579 01 03-01	Nut	2		
29	579 02 58-01	Screw	2		
30	725 54 53-01	Screw	4		
31	579 01 05-01	Nut	2		
32	510 36 15-01	Screw	20		
33	579 01 88-01	Jaw	2		
34	579 02 65-01	Crusher tip	2		
35	579 00 99-01	Sealing	1		

B BOOSTER
DCR 300



DCR 300 Page B					
Position	Article	Description	Qty	Notes	Kit
1	579 02 10-01	Hose	1		
2	579 02 22-01	Valve	1		
3	579 02 20-01	Valve	1		
4	579 02 11-01	Hose	1		
5	579 02 24-01	Manifold	1		
6	579 01 96-01	Check valve	3		
7	579 04 90-01	Adapter	4		
8	579 02 25-01	Slide ring	1		
9	579 02 27-01	Swivel	1		
10	579 00 98-01	Lubrication nipple	1		
11	579 02 28-01	Swivel bracket	1		
12	579 04 23-01	Screw	9		
13	579 02 67-01	Pipe	1		
14	579 02 15-01	Adapter	4		
15	579 01 91-01	Sealing	9		14
16	579 02 08-01	Hose	1		
17	579 04 24-01	Screw	4		
18	579 01 10-01	Manifold	1		
19	579 01 89-01	Plug	5		
20	579 04 89-01	Sealing	5		
21	579 02 03-01	Plug	1		
22	579 02 02-01	Sealing	1		
23	579 01 99-01	O-ring	10		
24	579 02 12-01	Adapter	1		
25	579 02 13-01	Valve	1		
26	579 02 17-01	Booster	1		
27	579 02 14-01	Pipe	1		
28	579 02 16-01	Support ring	2		
29	725 54 91-01	Screw	4		
30	579 02 18-01	Adapter plate	1		
31	579 02 19-01	Adapter	2		
32	579 01 92-01	Plug	1		
33	579 01 93-01	Check valve	1		34
34	579 01 98-01	O-ring	1		
35	579 03 77-01	Plug	1		
36	579 02 09-01	Hose	1		