

LG 164

Spare parts list

Forward plate

LG 164

General information

This spare parts list applies to the following:

Part number	Description
967897601	COMPACTORS LG 164 Hatz 350 mm
967897602	COMPACTORS LG 164 Hatz 450 mm
967897603	COMPACTORS LG 164 450 mm Hatz Bio
967897604	COMPACTORS LG 164 Hatz 600 mm
967897605	COMPACTORS LG 164 Hatz 450 mm EPA
967855601	COMPACTORS LG 164 Honda 450 mm
967855602	COMPACTORS LG 164 Honda 350 mm
967855603	COMPACTORS LG 164 Honda 450 mm Bio

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.

For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!

Preventative Maintenance Kits

Start Up Kit	1
12 months / 500 hours service kit	3
Start Up Kit, Hatz	5
12 months / 500 hours service kit	7
Six months / Every 250 hours kit	9

Service, repair and wear part kits

Shock absorber repair kit	11
Block paving plate kit 350 mm (13.7 in.)	13
Block paving plate kit 450 mm (17.7 in.)	15
Eccentric element repair kit	17
Forward and reverse piston repair kit	19
Transport device kit	21

Preventative Maintenance Kits

Spare parts list

Ground plate and engine plate Honda	23
Ground plate and engine plate Hatz	25
Ground plate and eccentric element installation	27
Eccentric element	29
Engine installation, Honda	32
Engine, Honda GX 160 UT2 SXS4 OH	36
Engine, Hatz 1B20	40
Engine installation, Hatz	45
Hydraulic system	47
Belt tightener	50
Centrifugal clutch, Hatz	53
Centrifugal clutch, Honda	55
Transport device	57
Handle Assembly	59
Lables	61

Preventative Maintenance Kits Start Up Kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	595385701	Start Up Kit	1	
2	595385801	500 Hours Service Kit / 12 Months Service Kit	1	
3	594445501	Air filter	1	
4	594189301	V-belt	1	
5	594302101	Air Filter, complete	1	
6	594302101	Air Filter, complete	1	
7	-	Cobra & compactor Impact-OIL 1L	2	

Preventative Maintenance Kits 12 months / 500 hours service kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
2	595385801	500 Hours Service Kit / 12 Months Service Kit	1	
3	594445501	Air filter	1	
4	594189301	V-belt	1	
5	594302101	Air Filter, complete	1	

Preventative Maintenance Kits Start Up Kit, Hatz

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM


Item	Part No.	Name	Qty	L
1	594218601	Start Up Kit	1	
2	594218701	12 months / 500 hours service kit	1	
3	595377401	Fuel filter	1	
4	595377301	Air Filter	1	
5	594332701	V-belt	1	
6	594445501	Air filter	1	
7	594214601	Six months / Every 250 hours kit	1	
8	595377401	Fuel filter	1	
9	595377301	Air Filter	1	
10	-	Cobra & compactor Impact-OIL 1L	2	

Preventative Maintenance Kits 12 months / 500 hours service kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	594218701	12 months / 500 hours service kit	1	
2	595377401	Fuel filter	1	
3	595377301	Air Filter	1	
4	594332701	V-belt	1	
5	594445501	Air filter	1	

Preventative Maintenance Kits Six months / Every 250 hours kit



Item	Part No.	Name	Qty	L
1	594214601	Six months / Every 250 hours kit	1	
2	595377401	Fuel filter	1	
3	595377301	Air Filter	1	

Service, repair and wear part kits Shock absorber repair kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	594196001	Shock absorber repair kit	1	
2	594477501	Shock absorber	4	A
3	595216101	Flange screw	4	A
4	595368901	Washer, 10.5 x 22 x 4 mm, 0.41 x 0.87 x 0.16 in. 300 HV	4	A
5	595113401	Washer DIN125	4	A
6	595351801	Hexagon nut m12	4	A
7	594524401	Shock absorber	4	B
8	594747401	Washer	7	B
9	594118401	Screw cap	4	B
10	594524501	Shock absorber	2	B
11	595036601	Washer DIN125	2	B
12	595035701	Nut DIN934	2	B
13	594462701	Shock absorber	1	B
14	595029401	Nut hexagon	1	B
15	594747001	Screw	1	


Comments for Page: Shock absorber repair kit

(L)OCAL REMARKS

A | See section "Ground plate and eccentric element installation".


B | See section "Handle".

Service, repair and wear part kits Block paving plate kit 350 mm (13.7 in.)



Item	Part No.	Name	Qty	L
1	595368501	Block paving plate kit	1	
-	--	Polyurethane plate, 350 mm, 13.7 in.	1	
-	--	Bracket	2	
-	--	Nut, M10 x 1.5 mm A3K	4	
-	--	Screw, M10 x 45 mm 4.6 A3K	4	

Service, repair and wear part kits Block paving plate kit 450 mm (17.7 in.)



Item	Part No.	Name	Qty	L
1	594830101	Block paving plate kit	1	
-	--	Polyurethane plate, 450 mm, 17.7 in.	1	
-	--	Bracket	2	
-	--	Nut, M10 x 1.5 mm A3K	4	
-	--	Screw, M10 x 45 mm 4.6 A3K	4	

Service, repair and wear part kits Eccentric element repair kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	594196701	Eccentric element repair kit	1	
2	594531101	Roller bearing	4	A
3	594547401	Sealing ring	1	A
4	594550501	Ball bearing	2	A
5	595046001	Retaining ring	1	A
6	595186801	Washer 6,4x12x1,5	16	A
7	595055001	Screw, M6x20 mm 8.8 A2K	16	A
8	594552101	Packing	1	A
9	594512101	COPPER WASHER	1	A

Comments for Page: Eccentric element repair kit

(L)OCAL REMARKS

A | See section "Eccentric element".

Service, repair and wear part kits Forward and reverse piston repair kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM


Item	Part No.	Name	Qty	L
1	594196501	Forward and reverse piston repair kit	1	
2	594332201	Sealing ring	1	A
3	594643301	Piston rod	1	A
4	594266401	Retaining ring	1	A
5	594647501	Ball bearing	1	A
6	594265601	Retaining ring	1	A
7	594647601	Thrust ball bearing	1	A
8	594647701	Spring washer	1	A
9	594643201	Hydraulic cylinder	1	A
10	595503001	Hydraulic Cylinder	1	A
11	595186801	Washer 6,4x12x1,5	4	A
12	595055001	Screw, M6x20 mm 8.8 A2K	4	A

Comments for Page: Forward and reverse piston repair kit

(L)OCAL REMARKS


A | See section "Eccentric element".

Service, repair and wear part kits Transport device kit



Item	Part No.	Name	Qty	L
1	594830501	Transport device kit	1	
-	--	Transport device	1	
-	--	Strap	1	
-	--	Washer, 13 x 36 x 6 mm, 0.51 x 1.42 x 0.24 in. 300 HV	1	
-	--	Screw, M12 x 25 mm 8.8 A3K	1	
-	--	Screw, M8 x 30 mm 8.8	4	
-	--	Wheel shaft	2	
-	--	Washer	4	
-	--	Wheel	2	
-	--	Split pin	2	
-	--	Washer, 8.4 x 22 x 3 mm, 0.33 x 0.87 x 0.12 in. 300 HV	4	
-	--	Nut, M8 A2K	4	

Spare parts list Ground plate and engine plate Honda




Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	595368601	Engine plate	1	
2	595352101	Locknut	2	
3	595216101	Flange screw	4	
4	594186401	Protective frame	1	
5	594150901	Lifting lug	1	
6	594469601	Clip	2	
7	594471501	Stop	2	
8	594119201	Bolt	2	
9	595115401	Washer	4	
10	595115401	Washer	1	
11	595128801	Clip	1	
12	595036501	Plain washer	2	
13	595109801	Hex. head screw	2	
16	594960201	Hood	1	
17	594121101	Screw	4	
18	595112601	Lock nut,M8	6	
19	595523901	Rubber cloth	2	
20	594185201	Distance	2	
21	595368901	Washer, 10.5 x 22 x 4 mm, 0.41 x 0.87 x 0.16 in. 300 HV	4	
22	595216101	Flange screw	4	
23	594478701	Throttle control, complete	1	
24	594758501	Wire	1	
25	595111501	Hexagonal soc contrsrnk screw	2	
26	595352201	Lock nut	2	
27	594126001	Cable tie	2	
28	595176801	Bracket	1	
29	595065801	Screw, M5 x 12 mm 10.9 FZB	1	
30	595465701	Screw, M6x16 mm 8.8 A2K	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Spare parts list Ground plate and engine plate Hatz



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	595368601	Engine plate	1	
2	595352101	Locknut	2	
3	595216101	Flange screw	4	
4	594186401	Protective frame	1	
5	594150901	Lifting lug	1	
6	594469601	Clip	2	
7	594471501	Stop	2	
8	594119201	Bolt	2	
9	595115401	Washer	4	
10	595369001	Bracket	1	
11	595128801	Clip	1	
12	595036501	Plain washer	2	
13	595109801	Hex. head screw	2	
16	594960201	Hood	1	
17	594121101	Screw	4	
18	595112601	Lock nut,M8	6	
19	595523901	Rubber cloth	2	
20	594185201	Distance	2	
21	595368901	Washer, 10.5 x 22 x 4 mm, 0.41 x 0.87 x 0.16 in. 300 HV	4	
22	595216101	Flange screw	4	
23	594176501	Throttle control EPA, complete	1	
24	594758601	Wire	1	
25	595111501	Hexagonal soc contrsrnk screw	2	
26	595352201	Lock nut	2	
27	594126001	Cable tie	2	
28	594481701	Throttle control Non EPA, complete	1	


Spare parts list Ground plate and eccentric element installation



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	595368801	Ground plate 350 mm	1	
2	594480901	Ground plate 450mm	1	
3	595464901	Ground plate 600 mm	1	
4	595351801	Hexagon nut m12	4	
5	595113401	Washer DIN125	4	
6	594437701	V-belt cover	1	
7	594478101	Protection	1	
8	595036601	Washer DIN125	6	
9	594117901	Hex. head screw m8 x 20	4	
10	595344301	Hex. head screw	2	
11	594512101	COPPER WASHER	2	
12	595057901	Screw, M10x20H	1	
13	595067901	Plain washer 13x24x4 mm	6	
14	594844101	Screw	6	
15	595048201	Edge trim	1	
16	595048201	Edge trim	1	
17	595048201	Edge trim	1	
18	594477501	Shock absorber	4	

Spare parts list Eccentric element



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	595176201	Eccentric housing	1	
2	595057801	Screw, M6x20 mm 8.8 A2K	2	
3	595186801	Washer 6,4x12x1,5	18	
4	595055001	Screw, M6x20 mm 8.8 A2K	16	
5	594435901	Cover	1	
6	595048301	Plug, M16	1	
7	595047801	Washer, 16.7x24x1.5 mm Type A M16	1	
8	594547401	Sealing ring	1	
9	594435801	Cover	1	
10	595050801	Feather key	1	
11	594478201	Pulley	1	
12	594326301	Washer	1	
13	595466201	Screw, M10 x 25 mm 8.8 A3K	1	
14	594643701	Cover	1	
15	594332201	Sealing ring	1	
16	594643301	Piston rod	1	
17	594645001	Cap	1	
18	594266401	Retaining ring	1	
19	594647501	Ball bearing	1	
20	594265601	Retaining ring	1	
21	594647601	Thrust ball bearing	1	
22	594647701	Spring washer	1	
23	594643501	Piston	1	
24	595062601	Spring pin	1	
25	595045801	Retaining ring	4	
26	594531101	Roller bearing	4	
27	594437401	Shaft, cpl	1	
28	594325901	Spacer ring	1	
29	594643601	Eccentric shaft	1	
30	594325201	Eccentric	1	
31	595066801	Washer, 13x24x2 mm 300 HV	1	
32	594526201	Screw, M12 x 30mm 10.9GEOMET®	1	A
33	594325801	Pin	1	
34	594550501	Ball bearing	2	
35	594653701	Gear wheel	1	
36	594326001	Spacer	1	
37	594546501	Screw	1	
38	594326901	Spring	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
39	594326201	Washer	2	
40	595046001	Retaining ring	1	
41	594803701	Eccentric	1	
42	594526301	Screw, M12 x 60 mm 10.9GEOMET®	1	
43	594643201	Hydraulic cylinder	1	

Comments for Page: Eccentric element


A || GEOMET is a registered trademark of Nof MetalCoatings North America Inc.

This page intentionally left blank

Spare parts list Engine installation, Honda



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594329901	Engine, Honda GX160UT2 SXS4 SD	1	A
2	595375101	Key	1	B
3	594485801	Clutch, cpl	1	
4	595068001	Washer, 8.4x26x4 mm 300 HV	1	
5	595055401	Screw, M8x20 mm 8.8 A2K	1	
6	595290301	Washer, 10x14x 1 mm	1	
7	594648201	Hose connection	1	
8	595454601	Hose clamp, 11-18 x 9 mm, 0.43 -0.71 x 0.35 in.	2	
9	594147801	Hose	1	
10	594147301	Plug	1	
11	595176801	Bracket	1	
12	595465701	Screw, M6x16 mm 8.8 A2K	1	
13	595065801	Screw, M5 x 12 mm 10.9 FZB	1	
14	594189301	V-belt	1	
16	595369801 	V-belt cover	1	
17	594123401	Washer, 8.4 x 16 x 1.5 mm, 0.33 x 0.63 x 0.06 in. 300 HV	4	
18	595110101	Hex. head screw m8 x 16	4	
19	594119001	Hex. head screw	1	
20	595066501	Steel Plain Washer	1	
21	594327901	Belt tightener	1	
22	594477801	Bracket	1	
23	595110301	Hex. head screw	2	
24	595347601	Screw, M5 x 25 mm	1	
25	594331001	Ryw-clips	1	
26	595344301	Hex. head screw	4	
27	595352401	Nut, M5 A2K	1	
28	595112701	Lock nut	2	
29	594124001	Washer, 13x36x6 mm, 0.51x1.42x0.24 ". 300HV	4	
30	595345201	Hex. head screw	2	
31	594143001	Strap	1	
38	595036601	Washer DIN125	4	
39	594827801	Deflector	1	
40	595034201	Screw		

Comments for Page: Engine installation, Honda

(L)OCAL REMARKS


Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

A | Honda GX160UT2 SXS4

B | Supplied with engine

This page intentionally left blank

Spare parts list Engine, Honda GX 160 UT2 SXS4 OH



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
1	594329901	Engine, Honda GX160UT2 SXS4 SD	1	
2	594203601	Silencer	1	
3	594204101	Gasket	1	
4	594300401	Gasket, muffler	1	
5	594204001	Plug, spark (bpr6es) (ngk)	1	
6	594203801	Cap assy., oil filler	1	
7	594203901	Gasket	1	
9	595048801	Gasket	1	
10	594204601	Fuel cap	1	
11	594204501	Fuel tank	1	
12	594204401	Switch assy., engine stop	1	
14	595048901	Oil plug gasket	1	
15	--	Engine part	1	
16	594572601	Gasket	1	
17	594203701	Carburetor	1	
18	595070001	Spacer	1	
19	595049301	Nut	1	
20	595049201	Cover	1	
21	595049301	Nut	1	
22	595049401	Grommet	1	
23	594302101	Air Filter, complete	1	
24	594582401	Air filter housing	1	
25	594300201	Muffler cover, upper	1	
27	594304501	Screw	1	
28	594304401	Guide	1	
29	594304201	Ratchet	2	
30	594304101	Spring	2	
31	594304301	Friction spring	1	
32	594304001	Reel	1	
33	---	Housing	1	
34	594303901	Spring	1	
35	594304801	Grip, starter	1	
36	595049101	Starting rope	1	
38	595381301	Adjustment screw	1	
39	594304401	Guide	1	
40	594204201	Ratchet	2	
41	594304101	Spring	2	
42	595131001	Friction washer	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
43	594204301	Reel	1	
44	---	Housing	1	
45	594303901	Spring	1	
46	594304801	Grip, starter	1	
47	595049101	Starting rope	1	
48	594204701	Friction spring	1	

This page intentionally left blank

Spare parts list Engine, Hatz 1B20



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	595365401	Engine, Hatz 1B20 EPA	2	D
2	595365301	Engine, Hatz 1B20 manual start EPA	1	
3	595176501	Engine, cpl Hatz 1B20, electrical started	1	
4	594479601	Engine, cpl Hatz 1B20 Non EPA version	1	
5	594570101	Oil strainer, cpl	1	
6	-	Tube	1	
7	-	Oil strainer	1	
8	-	O-ring	1	
9	-	Washer	1	
10	-	Screw	1	
11	594570201	Plug	1	
12	594513001	Washer	1	
13	594570401	Exhaust pipe	1	
14	594568401	Recoil starter, cpl	1	
15	594569901	Starter pulley	1	
16	-	Screw	1	
17	-	Washer	1	
18	594569201	Spring	1	
19	-	Federring	1	
20	-	Screw	1	
21	595373301	Fricion plate	1	
22	594569701	O-ring	1	
23	594569101	Reel	1	
24	594569601	Ratchet	1	
25	-	Start pulley	1	
26	594568501	Handle, complete	1	
27	594202401	Sleeve	1	
28	-	Handle	1	
29	594202501	Washer, 5.3 mm, 0.21 in.	1	
30	594568601	Spiral spring	1	
31	595373401	Housing	1	
32	-	Washer	4	
33	-	Screw	4	
34	594569001	Starting rope	1	
35	594202701	Air filter housing, complete	1	
36	-	Vent nipple	1	
37	-	Housing	1	
38	-	Sealing strip	1	


Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
39	-	Sealing strip	1	
40	595377301	Air Filter	1	
41	-	Valve plate	1	
42	-	Valve plate	1	
43	-	Rubber sleeve	1	
44	594572001	Gasket	2	
45	595470201	Gasket	1	
46	594571201	Nut	1	
47	594191001	Protecting cover	1	
48	594578001	Oil dipstick	1	
49	-	Dipstick	1	
50	594605501	O-ring	1	
51	595372801	Injection pump	1	
52	-	Pump part	1	
53	-	Pump part	1	
54	-	Pump part	1	
55	-	Pump part	1	
56	-	Pump part	1	
57	-	Pump part	1	
58	-	Pump part	1	
59	-	Pump part	1	
60	-	Pump part	1	
61	-	Pump part	1	
62	595190301	O-ring 0,2 mm	1	
63	594568001	O-ring 0,3 mm	1	
64	594568101	O-ring 0,4 mm	1	
65	594568201	O-ring 0,5 mm	1	
66	594568301	O-ring 0,6 mm	1	
67	594202901	Injector, complete	1	
68	-	Injector part	1	
69	-	Injector part	1	
70	-	Injector part	1	
71	-	Injector part	1	
72	-	Injector part	1	
73	-	Injector part	1	
74	-	Injector part	1	
75	-	Injector part	1	
76	-	Injector part	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
77	-	Injector part	1	
78	-	Injector part	1	
79	-	Injector part	1	
80	-	Injector part	1	
81	-	Injector part	1	
82	594585201	Starter	1	
83	594594801	Instrument box, cpl	1	
84	-	Circuit card	1	
85	-	Housing	1	
86	595129401	Ignition switch	1	
87	-	Ignition switch part	1	
88	-	Ignition switch part	1	
89	-	Ignition switch part	1	
90	595373601	Dust cover	1	
91	594205701	Ignition key	1	

Spare parts list Engine installation, Hatz



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
1	594479601	Engine, cpl Hatz 1B20 Non EPA version	1	A
2	595365301	Engine, Hatz 1B20 manual start EPA	1	
3	595112901	Washer, 8.4 x 26 x 4 mm, 0.33 x 1.02 x 0.16 in. 300 HV	1	
4	595033401	Hex. head screw	1	
5	594332701	V-belt	1	
7	595279001	V-belt cover	1	
9	594119001	Hex. head screw	1	
10	595112801	Washer, 10.5 x 22 x 4 mm, 0.41 x 0.87 x 0.16 in. 300 HV	1	
11	594327901	Belt tightener	1	
13	595110301	Hex. head screw	2	
15	595344301	Hex. head screw	4	
16	595036601	Washer DIN125	4	
17	594124001	Washer, 13x36x6 mm, 0.51x1.42x0.24 ". 300HV	4	
18	595112701	Lock nut	2	
19	595345201	Hex. head screw	2	
20	594143001	Strap	2	
21	595124401	Strap	1	
22	594431001	Clutch, cpl	1	
28	594181501	Distance sleeve	4	
29	594827801	Deflector	1	
30	595034201	Screw	1	

Comments for Page: Engine installation, Hatz

(L)OCAL REMARKS

A | EPA (US Environmental Protection Agency). Version for US and Canada market.

Spare parts list Hydraulic system



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
1	594426301	Hydraulic oil tank, complete	1	
2	--	Hydraulic oil tank	1	
3	594445501	Air filter	1	
4	594445401	Holder	1	
5	594838801	Screw, K50 x 12 mm Type KX-PT	2	
6	594443101	Cover with oil dipstick	1	
7	595066601	Washer, 8.4x 6x1.5 mm 300HV	1	
8	595465901	Screw, M8x25 mm 8.8 A2K	1	
9	595047301	O-ring	1	
10	595344701	Hex. head screw	4	
11	595113301	Washer plain	4	
12	594426001	Adapter	1	
13	595160701	Hose clamp	1	
14	595069301	Hose connection	1	
15	595454701	Hose clamp	1	
16	594480201	Hydraulic hose	1	
17	594478001	Hydraulic hose	1	
18	594497601	Hydraulic hose	1	
19	594497701	Hydraulic hose	1	
20	594524101	Elbow 90 orfs	2	
21	594324301	Cover	1	
22	594523701	Elbow	1	
23	594455301	Hydraulic pump	1	
24	595186801	Washer 6,4x12x1,5	2	
25	595057801	Screw, M6x20 mm 8.8 A2K	2	
26	594547101	Key	1	
27	594548901	Sleeve	1	
28	595059401	Hexagon nut M6	1	
29	594524201	Pipe clamp block	1	
30	595036501	Plain washer	1	
31	595348101	Hex sock. screw	1	
32	594518601	Connector	3	
33	594347601	Valve, complete	1	
34	-	Valve body	1	
38	595369201	Lever	1	
39	594208601	Housing	1	
40	595033401	Hex. head screw	2	
41	595036601	Washer DIN125	8	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
42	594208701	Pin	1	
45	595110101	Hex. head screw m8 x 16	2	
46	595110001	Screw, M6 x 55 mm 8.8 A2K	2	
47	595036501	Plain washer	2	
48	595036001	Nut	2	


This page intentionally left blank

Spare parts list Belt tightener




Item	Part No.	Name	Qty	L
1	594327901	Belt tightener	1	
2	594328101	Shaft	1	
3	595045001	deep groove ball bearing	1	
4	594124701	Circlip	1	
5	595144901	Bore Circlip	1	
6	594328001	V-belt pulley	1	
7	594119001	Hex. head screw	1	
8	595066501	Steel Plain Washer	1	

Spare parts list Centrifugal clutch, Hatz




Item	Part No.	Name	Qty	L
1	594431001	Clutch, cpl	1	
2	594572201	V-belt pulley	1	
3	594584301	Ball bearing	1	
4	594584401	Retaining ring	1	
5	594584501	Snap ring	2	
6	595143301	Nilos ring	1	
7	594572301	Hub	1	
8	594147701	Clutch weight	2	
9	595192801	Clutch lining	2	
11	594313101	Cover	1	
12	594308801	Retaining ring	1	
13	594312301	Cover	1	
14	594311901	Retaining ring	1	

Spare parts list Centrifugal clutch, Honda



Item	Part No.	Name	Qty	L
1	594485801	Clutch, cpl	1	
2	594609901	V-belt pulley	1	
3	595470301	Bearing	1	
4	595470401	Retaining ring	1	
5	595470501	Retaining ring	1	
6	594584001	Hub	1	
7	594301401	Weight	2	
8	594606601	Clutch lining kit	1	
9	---	Clutch lining	2	
10	---	Spring	2	
11	594312301	Cover	2	
12	594311901	Retaining ring	2	


Spare parts list Transport device



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594486401	Transport device	1	
2	595124401	Strap	1	
3	-	Washer, 13 x 36 x 6 mm, 0.51 x 1.42 x 0.24 in. 300 HV	1	
4	-	Screw, M12 x 25 mm 8.8 A3K	1	
5	-	Screw, M8 x 30 mm 8.8	4	
6	594486601	Wheel bracket	2	
7	594316201	Washer	4	
8	594455801	Wheel	2	
9	595343501	Cotter pin	2	
10	-	Washer, 8.4 x 22 x 3 mm, 0.33 x 0.87 x 0.12 in. 300 HV	4	
11	-	Nut, M8 A2K	4	


Spare parts list Handle Assembly



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	595369301	Handle	1	
2	595369501	Cover	1	
3	595110101	Hex. head screw m8 x 16	4	
4	595036601	Washer DIN125	9	
5	595189001	Protective plug	2	
6	594747001	Screw	1	
7	594747401	Washer	10	
8	594462701	Shock absorber	1	
9	594451501	Hook	1	
10	595029401	Nut hexagon	1	
11	595464601	Bracket	2	
12	594118401	Screw cap	4	
13	594524501	Shock absorber	2	
15	594123101	Locknut	2	
16	594524401	Shock absorber	4	
17	594118601	Screw hexagon	2	
19	595035701	Nut DIN934	1	
20	594524601	Plastic washer	2	
21	-	Plug	1	

Spare parts list Lables



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594660601	Safety label, lock handle	1	
2	594660701	Label, operator panel	1	
3	594869701	Decal safety	1	
4	595216301	Decal, noise level 108 dB	1	
5	594660901	label, lifting point	1	
6	594464001	Safety label, rotating V-belts	1	
7	594661601	Label, fuel	1	
8	594660501	Label, throttle control non EPA	1	
9	594869601	Label, manual start	1	
10	595512801	Label, hydraulic oil level	1	
11	594659601	Safety label, read instructions, ear protection and safety boots	1	
12	595216501	Gas Throttle Control Honda	1	
13	595513501	Logotype	1	
14	595216801	Logotype	1	
15	595514001	Decal LG 164	1	
16	595469401	Decal biodegradable hydraulic oil	1	
17	595216601	Label, Gas throttle Control Hatz	1	
18	595216401	PETROL FUEL	1	
19	594659801	Safety label, hot surfaces	1	

Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.